

CATALOG NUMBER

ECMFH

PowerMod™ Horn Bypass Kit



⚠ DANGER

Hazardous Voltage.
Will cause death, serious injury
or substantial property damage.

Turn off power supplying this
equipment before working inside.

Kit Contents:

- (4) Bypass Horns
- (4) Screws, #10-32 x 7/16

Note: This instruction outlines the recommended installation procedure. For installation by a qualified person, as defined by all local electrical codes and/or the National Electrical Code ®.

1. Turn off and lock off the power supplying the device before working inside.
2. Clean and prepare surface; remove any old or damaged material before installing replacement part. Do not allow petroleum based (hydrocarbon) sprays, chemicals, solvents or any paint to contact plastic components.
3. Install Horns as shown with Horn tongue facing away from meter socket.
4. Install #10 Screws, tighten to 20-25 lb.-in.

Siemens Energy & Automation, Inc Alpharetta, Georgia U.S.A. 4819958 Rev.A

© The National Electrical Code is a registered trademark of the National Fire Protection Association.
© 2009 Copyright Siemens Energy & Automation, Inc.

