## SIEMENS


**Replacement Parts** 

March, 2016

## For replacement parts information or an application guide, visit our website at www.usa.siemens.com/controls, or contact your local Siemens sales office.


## E87010-A0093-T010-A4-87JC

Pump Panel Size 3, 3<sup>1</sup>/<sub>2</sub>



Item	Part Name			Part Number
В	Switch Block Assembly	250V/600V	100A 200A	HFB63 MCS620R
С	Load Base Assembly (Base, Clips, Lugs, Hardware)	250V/600V	100A	HBB63
		250V/600V	200A	FCK620
E	Motor Circuit Protector	600 VAC	100A 125A	ED63A100 ED63A125
F	Handle Only	for Disconnect	100A	75D73944015
	Complete Handle Assembly Yoke Lever (Not Shown)	for Disconnect for Circuit Breaker	200A	75D73944023 75D73944025
		for Disconnect	100A	75D68257103
		for Disconnect	200A	75D68257068
		for Circuit Breaker		75D68257080
G	H-O-A Selector Switch			52SA2CBA1
Н	Start Push Button			52PA8A1K
К	Reset Assembly			49MBRS

Page 2



Item	Part Name			Part Number
			Motor FLA	Λ.
A	Starterwith ESP200	Size 3 Size 3½	25-100A 50-200A	14HUG32A* 14IUH32A*
	Starter with Ambient Compensated Bimetal Overload Relay	Size 3 Size 3½		14HP32A*81 14IP32A*81
A <sub>1</sub>	Contacts & Spring, One Complete Pole	Size 3 Size 3½		75HF14 75IF14
A <sub>2</sub>	Auxiliary Contact			49AB10
A <sub>3</sub>	Coil 60 Hz	50 Hz		
	110-120 / 220-240V 220-240/ 440-480V 200-208V	110 / 190-220V 190-220/ 380-440V		75D73251A 75D73251C 75D73251D
	550-600V	550V		75D73251E
A <sub>4</sub>	ESP200 Overload Relay Only	Size 3 Size 3½	25-100A 50-200A	48BTG3S00 (3UB81334GW2) 48BTH3S00 (3UB81334HW2)
	Ambient Compensated Bimetal Overload Relay	Size 3 & 31/2		48HC38AA3

Note:When ordering replacement parts, give catalog number of control and part name and number. Replace the (\*) with letter from the coil table.

Coil Table	
60 Hz Voltage	Letter
110-120/220-240	
220-240/440-480	С
200-208	D
550-600	Е